



Tikka Stock Installation Guide

In many instances, on your factory Tikka trigger guard, there is a remnant from injection moulding, known as a sprue - as shown below.



This must be removed prior to installation into any Kroseg Precision stock. This can be removed by simply twisting off with pliers, or cutting with a blade. See images below of removed sprue.



Torque settings for this stock - 45 inch lbs without pillars installed.
- 65 inch lbs with pillars installed.